

Spreadsheet for calculating earth pressure force, sliding and tipping values of retaining wall profiles.

Two methods each are shown for tipping and sliding. "a" means "active", "h" horizontal, "v" vertical, "g" component due to gravity, "p" component due to load pressure.

Input values in orange cells. Main outputs are safety factors or position of force vector (distance from toe or eccentricity. If SF = 1 this means the profile is starting to tip or slide, less it has failed, more it is stable. Recommended safety factors range from 1.2 (CAPEB sliding case "g") to approx. 3 (DIN tipping case "g+p"). If in doubt use min. 1.5 for everything or 1.5 for sliding, 2 for tipping and always case "g+p".